

SlideRenu®

Residential FIBERGLASS Water Slide Resurfacing Kit SURFACE PREPARATION AND APPLICATION INSTRUCTIONS

Materials you will need:

- Acetone solvent – 1 quart
- Clean rags - 3

Materials included in SlideRenu® Residential Kit:

- SlideDetergent™ – 1 Pint
- SlideGloss™ – 1 Pint
- Roller frame - 1
- 3/8" Roller cover - 2
- One-quart kit of ColorShield UV4™ * (26 ounces of Part A and 6 ounces of Part B)
- Two-quart kit of ColorShield UV4™ * (51 ounces of Part A and 13 ounces of Part B)
- 80 grit sandpaper - 1
- 1000 grit fine sandpaper - 1
- Measuring/mixing cup - 1
- Paint stirrer - 2
- Can opener - 1
- Gloves – 2 pair

Surface Preparation and Application Instructions:

1. Spray on SlideDetergent™, let sit for 2-3 minutes. Scrub with brush or 3M pad. Rinse off with water.
2. Sand surface with 80 grit sandpaper. Rinse off with water and let dry.
3. Apply acetone solvent to clean rag and wipe surface. Let dry.
4. Using the supplied measuring cups, mix ColorShield UV4™ - 4:1. (Mix 4 parts of A to 1 part of B. Example: 4 ounces of A and 1 ounces of B.) Do not pour into measuring cup without measuring and only measure out what you will use in 1 hour. **Once mixed, the product cannot be stored for future use.**
5. Apply ColorShield UV4™ using the 3/8" nap roller cover provided. Let dry overnight. Apply a second coat to the entire surface within 24 hours. If more than 24 hours, lightly sand surface with 80 grit sandpaper (Wipe with acetone solvent in between coats.)
6. 72 hours after final coat has been applied, wet-sand any rough areas *lightly* with 1000 grit sandpaper and rinse off with water.
7. Spray on/wipe off SlideGloss™ finishing wax (SlideGloss™ may be used anytime you want to add more Slip-N-Shine™ to the riding surface.)

* 1 Quart Kit - RK032FG - \$ 150.00

* 2 Quart Kit - RK064FG - \$ 300.00

Date Prepared: 1 June 2022

**NOTE: RESIDENTIAL COLORS ARE LIMITED TO WHITE, LIGHT BLUE AND STAR BLUE.
OTHER COLORS ARE AVAILABLE BUT MUST BE PURCHASED IN 1 GALLON KITS.**